


SPARE PARTS

MX6



SPARE PARTS

MX6

Parts

Part No	Description
1	A0173800 MX Hose Float
2	30023900 Top Cover w/Swivel Assembly
3	F0106100 Screw, M4X12mm, Phillips #2 Pan Head (Pack of 5)
4	30031100 Middle Engine Housing w/Ramp & 2 seals, MX6
5	A0211400 MX6 Cover Latch
6	R0595101 Drive Pulley Assembly - MX6
7	W7230223PK Bearing (Wheel & Engine)
8	11162900C Engine Assembly, MX6/MX8
9	30022700 Drive Shaft Assembly, MX6/MX8
10	A0211500 MX6 Body Panel, Right (D)
11	A0165500 Lower Engine Housing, Side A
	A0165600 Lower Engine Housing, Side B
12	A0211100 MX6 Body Panel, Rear (B)
13	F0106600 Screw, Thread Forming, #6 - 18 7/8 in Type A, Phillips #2, Pan Head (Pack of 5)
14	11162600 Directional Control Device, Side A
15	A0211200 Body Panel, Left (C)
16	A0166100PK MX Track 2PK
17	A0203000 MX Wheel Pin
18	A0166000 MX Wheel
19	30024100 Chassis Assembly
20	A0211000 MX6 Body Panel, Front (A)
21	A0210100 Lower Body Housing
22	11163100 MX Scrubber Assembly
23	A0164500 Global Hose
	W26060 Jumbo Global Hose (Pack of 30)
24	W70281C AD Flow Valve
25	W70263 Universal Weir Cuff
26	A0219700 90 Degree Flow Elbow
28	FRV100 Flow Regulator Valve (FRV)